



How to

use the "Green Cable" with Simatic Manager from Siemens

For using the "Green Cable" with Simatic Manager from Siemens, you have to select the PC Adapter (MPI) and the baud rate 38400Baud.

Approach:

1. Open your Simatic Manager from Siemens
2. Click at menu *Options > Set PG/PC interface...*
3. Now the *Set PG/PC Interface..* dialog opens.
4. In this dialog select the interface *PC Adapter (MPI)*.
5. Click on *Properties...*, select the correct COM port, the *Transmission Rate 38400* (bit per second). Click OK and again OK. Now the settings are correct.
6. Connect the male connector of the "Green Cable" to the MP²I interface of the PLC, the female connector to the PC.
7. Click on menu *PLC > Display Accessible Nodes*, now you should see a window with a symbol for one or more PLCs with their MPI address, e.g. MPI=2. You are online now!

With the same settings you can use also a PC to MPI adapter. On the original Siemens adapter you have to check the position of the baud rate selection switch, set it to 38.4 (38.4kBaud).